



سلام. من احمد نوروزي هستم. ميخوام براتون كل **كدها**

ورمزهاي مخفي موبایل ها **رو بگم**. اين كدها (رمزها) ♦♦ ۱%

صحيح هستن، من خودم اينارو امتحان کردم، نه همشون رو فقط روي گوشسيهائي
مثل: نوکيا، سامسونگ، سوني اريکسون امتحان کردم، جواب داد، حالا شما هم ميتونيد
امتحان کنيد.....

(اما يه چيزي ناگفته نماند، من براي اين کدها ورمزها کلي هزينه وکلي سختي کشيدم، حتي براي نوشتن اين کدها
ورمزها، اميدوارم که لذت کافي را بيريدي)

بسمه تعالي

تهيه و تنظيم: احمد نوروزي

ahmadnoroozi1372.blogfa.com

احمد نوروزي

Samsung Service Codes

*#06#	Show IMEI
*#9999#	Show Software Version
*#0837#	Show Software Version (instructions)
*#0001#	Show Serial Parameters
*#9125#	Activates the smiley when charging
*#0523#	LCD Contrast
*2767*3855#	FULL E2P RESET
*2767*2878#	CUSTOM E2P RESET
*#7337#	UNLOCK
*2767*688#	UNLOCK
*#0523#	CONTRAST
*#9998*523#	CONTRAST

Samsung Сервисные коды Функция Комбинация:

вывод IMEI-кода (International Mobile Equipment Identity)
вывод версии программного обеспечения

*#06#
*#9999#

вывод версии программного обеспечения (instructions)	*#0837#
вывод серийных параметров	*#0001#
меню регулировки дисплея	*#0523#
изменение контрастности дисплея (только для версии G60RL01W)	*#9998*523#
изменение частоты звонка	*#9998*289#
статус памяти	*#9998*636#
размер SIM-файла	*#9998*746#
Сервисная таблица SIM-карты	*#9998*778#
статус батареи (емкость, напряжение, температура)	*#9998*228#
тест вибратора	*#9998*842#
Установка режима смайлов в режиме зарядки	*#9125#
par Установка режима голосового кодера (нормальная, наушник или громкая связь)	*#9998*862#
Изменение серийных параметров	*0001*s*f*t#
экран отладчика	*#9998*324#
Полный сброс EEPROM (SP-разблокировка!)	
Также изменяет IMEI на 447967-89-400044-0	*2767*3855#
Пользовательский сброс EEPROM	*2767*2878#
Меню регулировки дисплея	*#0523#

*2767*3855# - FULL E2P RESET
 *2767*2878# - CUSTOM E2P RESET
 #*7337# - UNLOCK
 *2767*688# - UNLOCK
 *#0523# - CONTRAST
 *#9998*523# - CONTRAST

!!! Reset-Codes !!!

!!! diese Codes nur dann anwenden, wenn ihr wisst was ihr tut !!!

!!! Damit werden Daten im Handy gelöscht !!!

*2767*3855# FULL Reset
 *2767*2878# CUST Reset
 *2767*927# WAP Reset
 *2767*667# MMS Reset
 *2767*36245# Email Reset

SGH C100, C110

[*#32436837#] Service code

SGH X100, X600

***#8999*8378#** Service Menu
#*7337# Unlock
***2767*2878#** Custom E2P Reset:
"*2767*927#" WAP Reset
***2767*3855#** Full E2P Reset:

SGH E700

***2767*688#** remove USER CODE and SIMLOCK

SGH S500 Unlocking

***2767*MVT# (*2767*688#)** E2P MVT Reset

***#SIMLOCK# (*#7465625#)**

SGH A800

***#8999*8378#** - Service menu

***2767*637#** - Unlock

SGH V200 Unlocking:

Power on the phone without SIM card and type these codes:

***2767*63342#** and press green button

***2767*3855#** and press green button

***2767*2878#** and press green button

***2767*927#** and press green button

***2767*7822573738#** press button

Phone will be unlocked, but all trims are reseted!

Mobile phone must be fully charged

SGH R210, T100, A300...

if code is in format ***#9998*xxx#**

try write in this ***#0xxx#**

SGH-600, SGH-2100

***2767*2878#** Custom EEPROM Reset

***2767*3855#** Full EEPROM Reset

(THIS CODE REMMOVES SP-LOCK!

but also changes IMEI to **447967-89-400044-0**

SGH R200 SGH R210 SGH R220.....

ahmadnoroozi1372.blogfa.com

احمد نوروزي

Nokia Service Codes

***#06#** IMEI

***#0000#** view Software Version

***#746025625#** [*#sim0clock#]

***#92702689#** [*#war0anty#] secret menu:

1. Displays Serial Number

2. Displays the Month and Year of Manufacture (0997)

3. Displays (if there) the date where the phone was purchased
4. Displays the date of last repairment - if found (0000)
5. Makes you capable of transferring user data
6. Shows how many hours the phone has been on

***3370#** Enhanced Full Rate Codec (EFR) activation
#3370# Enhanced Full Rate Codec (EFR) deactivation
***4370#** Half Rate Codec activation
#4370# Half Rate Codec deactivation
xx# - xx position in Phone Book

Nokia 5140:

***#7780#** сброс настроек

Nokia 6230:

***#7370925538#** (valet code reset)

#746025625#** [#sim0clock#**]

#92702689#** [#war0anty#**]

NOKIA 7650:

***#7979#** phone reset

***#7470#** hard reset

***#7370#** master reset (like new phone)

NOKIA 9000:

***#06#** IMEI

***#3283#** prod. date

***#682371158412125#** soft version

Смартфоны:

***#06#** - IMEI смартфона

(IMEI номер - состоит из 15 цифр, он уникален и есть у каждого телефона).

Этот номер должен совпадать с номером на коробке.

***#0000#** - номер прошивки

Загрузка в Safe Mode:

1. Выключить телефон
2. Нажать "КАРАНДАШ" (и НЕ отпускать)
3. Нажать кнопку включения
4. Держать "КАРАНДАШ" до ПОЛНОЙ загрузки!!!

***#7780#** - восстановление исходных (рабочих) настроек смарта

***#7370#** - сбросить смарт в заводские настройки
(т.е. удаляется весь софт, контакты, календарь и пр
- смарт становится чистым!)

ВНИМАНИЕ! Для использования последних двух кодов

надо будет ввести код блокировки телефона (по умо 'евчанию **12345**)!

***#2820#** - уникальный адрес Bluetooth-модуля вашего девайса
(может понадобится другим устройствам,
которые не умеют отображать имена).

***#7370925538#** - очиска "Бумажника"
(для **Nokia 6600** и выше - в которых есть "Бумажник").

***3370#** (телефон должен перезагрузиться)
улучшает качество звука (использование EFR),
но уменьшает время работы батареи.

#3370# - сбрасывает качество звука к нормальному (отменяет код ***3370#**).
EFR CODEC (Enhanced Full Rate)

Данная функция при ее включении, по идее,
должна значительно улучшить качество передаваемой речи,
но, к сожалению, она должна поддерживаться оператором сотовой связи.
При ее работе слегка повышается энергопотребление телефона
в режиме разговора (около 5%). Насколько известно,
ни один из российских сотовых операторов не поддерживает эту функцию.
Принцип основан на другом алгоритме сжатия речи (ACELP)
и занимает более широкую полосу частот.

***4720#** - включить Half Rate Codec (HFR)
#4720# - отключить Half Rate Codec (HFR)

HR CODEC (Half Rate)

Значительно ухудшает качество речи,
но экономит аккумулятор где-то на 30%.
Опять же, должен поддерживаться сотовым оператором.

#92702689#** - вход в сервисное меню [#war0anty#**]

lahmadnoroozi1372.blogfa.com احمد نوروزي

Sony-Ericsson Service Codes

*#06#	Show IMEI
>*<*<*	Service menu
<*<	Lock menu
*#0000#	Fast english menu
**04*0000*0000*0000#	menu without SIM

GA628:
***#103# YES** date and time

Alcatel Service Codes

*#06#	Show IMEI & SW version
000000*	Entering in Engineering Menu1 (with SIM)
###337*07#	Master reset (with SIM)
###874#	Reset to Factory Defaults (with SIM)
###847#	Factory reset (with SIM)
###765*02#	Add Barring Groups
###765*05#	Locking to Network
###765*07#	Unlocking from Network
###765*08#	Erase Network
###765*78#	Deactivate Barring Groups
0123456789	Menu2 Code - BE4 Menu2 - turn long CALL in Maenu1
*#0048#	Fast change language (Polish)
*#0049#	Fast change language (Deutsch)

Alcatel 835

**0102#	Formating
----------------	-----------

Alcatel Master Codes:

25228352 BE1, BE3:
25228353 HD1, HE1:
83227423 BE4, BE5 (TH3/4,BH4,BF5,BG3,BF3/4..)

Fly Bird Service Codes

Fly Bird S288, S688

***#301#02# send** - with SIM menu: **7 - 10 - ok**,
***#8000#**, ***#3676#** (reboot repair)

V09, S1180

***, 3 times down, 3 times up** - Service Menu

4268#* (удерживать)

lahmadnoroozi1372.blogfa.com

Bosh Service Codes

***#06#** IMEI (INTERNATIONAL MOBILE EQUIPMENT IDENTITY)

***#0000#** Language automaticaly (reset to english)

***#3370#** Enhaced Full Rate

***#3370#** Reset the phone

***#9000#** Enter sim lock code

***#9001#** Enter the corporate code (Bosch 908)

***#9002#** Enter the provider code (Bosch 908)

***#9003#** Enter the network code

***#9004#** Enter the subset code

***#9100#** Remove the sim lock permanently

***#9101#** Remove the corporate lock permanently

***#9102#** Remove the provider lock permanently

***#9103#** Remove the network lock permanently

***#9104#** Remove the subset lock permanently

***#3262255*8378# (*#DANCALL*TEST#)** Hidden 10th menu

lahmadnoroozi1372.blogfa.com

CDMA Service Codes:

Модель

Audiovox 107

Audiovox 120

Audiovox 130,100,8300,8600

AUDIVOX 7900

Audiovox 4000,9500

CyberBell 100

Ericsson

EVRC

GTRAN GCP-2000

Hunday-110

Hunday-600

LG-300

LG-330

LG CX300V

Сервисный режим

45680*47*869#1

#8690489397#**

##20022002"END"1

MENU#ПИСЬМО*1 10CEK

289F#1

##1475369908##"save"

923885"Menu"

#763*FF

01#737

#8690489397#**

##20022002"END"1 код 100499

"Menu" 9

"Menu" 40

"Menu" 0

LG-800
LG 111
for Nokia

"Menu" 0
"Menu" -> 3 -> 0
***3001#12345#**

Huawei (CDMA)

MASTER SECURITY CODE

309296, 3092, 9296

Pantech HX-550C (CDMA)

Full reset (phone code reset) **##03*934#9367*192#397#7412569746 PWR**,
after reset - **##27732726 PWR** and select "with uim"

включение Net Monitor в куретеле 510 **##27732726 pwr**

Programming:

Samsung

All type of phones (old models):

NAM programming: 47*869#08#9

Test mode: *759#813580 or 5809540*45680

Exit test mode - 02

A-Key: menu + 0, code 25##

Samsung A400 and A460:

1. Enter ## and OTKSL
2. Press 1 for Basic at MENU (1 of Phone # when using the MSL)
3. Enter 10 digit MIN and press OK
4. At 1.Basic Menu press the END key
5. Handset will power cycle

Samsung A500:

1. Enter ## and the 6 digit OTKSL
2. SERVICE MENU will appear and 1.Basic will be highlighted
3. Press OK
4. Device will display NAM CDMA/ Phone Number
5. Enter 10 digit MIN
6. Press OK (3 times)
7. Display will return to Service Menu. Press END.
8. Programming is complete

Samsung N240 and N400 programming:

1. Enter ## and type in the 6 digit OTKSL
2. The display will show SVC MENU and 1. Phone Number
3. Press OK
4. Enter the 10 digit MIN and press OK
5. The display will show NAM with Home SID on the second line
(Note: SID is no longer used)
6. Press OK
7. The display will return to the SVC MENU
8. Press END to complete the programming

Samsung Uproar programming:

1. Press MENU key
2. Enter 9 2 0
3. Enter the OTKSL
4. At SVC Menu screen press OK
5. Enter MIN and press OK 4 times
6. Enter SID (4654) and press OK
7. Press END key
8. Programming is complete

Samsung N300 programming:

1. Press ## followed by the OTKSL
2. SVC menu will be displayed
3. Press 1 for Phone #
4. Enter the 10 digit MIN and press OK
5. MIN that was entered will be displayed press OK
6. SVC Menu will display press 3 for NAM
7. Enter the 4 digit Home SID press OK
8. Press END and handset will power cycle

Samsung i300 programming:

1. Tap on the Phone Icon with stylus
2. Press #907*9#0 ENTER LOCK should appear on screen
3. ENTER OTKSL
4. SVC MENU will appear press 1
5. Enter 10 digit MIN and then press SAVE
6. Press SAVE again
7. Press 3 and then press SAVE 6 times
8. Enter the HOME SID and press SAVE once
9. Press END key twice

Samsung 3500 8500 6100 N200 programming:

1. Press MENU
2. Press 6 0 (3500) 8 2 0 (8500/6100/N200)
3. Enter OTKSL
4. Press 1 at SVC MENU Screen
5. Enter MIN and press OK
6. Press OK 4 times
7. Enter SID (4654) and press OK
8. Press END key
9. Programming is complete

Qualcomm programming:

QCP-800 programming: menu + 3 + 0.
SPC: "000000" or may be other SPC typed by user.
QCP-820/1920/2035: type "111111" and press Jog Dial.
Choose "Programming" and enter SPC: "000000"
or may be other SPC typed by user.

QCP 1960 and 2760

1. Press softkey under the work MENU
2. Press 8 0
3. Enter the OTKSL
4. Press softkey for OK
5. Enter MIN and press softkey for OK
6. No SID is require for this handset
7. Press softkey for EXIT
8. Programming is complete

LG:

LG C-300 programming:

menu + 9 and enter SPC: "000000" or may be other SPC typed by user
A-Key: press STO for some time while you can see special code enter zone.
Type 2539** and enter A-key

LG C-330W programming:

menu + 4 + 0 and enter SPC: "000000"
or may be other SPC typed by user.
A-Key: type 2539** and enter A-key

LG C-800W /500 programming:

menu + 0 and enter SPC: "000000" or may be other SPC typed by user.
A-Key: type 2539** and enter A-key

LG C-510 programming:

menu + 3 + 0 and enter SPC: "000000"
or may be other SPC typed by user.
A-Key: type 2539** and enter A-key

LG 1010 LG 4NE1 TP2200 TP2100 Touchpoint SB/DB TP 1100 TP5200

1. Press ##
2. Enter the OTKSL
3. Scroll to SAVE and press OK
4. Scroll to MIN and press OK
5. Enter 10 digit MIN scroll to SAVE and press OK
6. Scroll to SID and press OK
(Skip on 4NE1 go to RESET PHONE and press OK to complete)
7. Enter SID (4654) and scroll to SAVE and press OK
8. Programming is complete

LG 5350 programming:

1. Enter ## and enter the OTKSL and press the left soft key under the word "Save"
2. At the Service Program display select Mobile Phone #
and press the OK in the center of the 4 way navigation key
3. Enter the 10 digit MIN and press OK
4. Scroll down to 4. Advanced and press OK
5. Scroll to NMSI and press OK
6. Enter the MSID and press OK
7. Scroll down to 9. Amps Phone # and press OK

8. Enter the MSID and press OK
9. Press the END key

TP 2100 programming:

1. Press ##
2. Enter OTKSL
3. Scroll to SAVE and press Roller Ball in for OK (ESN will display)
4. Select NEXT (by pressing in the roller ball)
5. Scroll to EDIT and press in the roller ball
6. Enter MIN
7. Scroll to SAVE and press roller ball in
8. Select NEXT at the next 3 screens and then EXIT
9. Programming is complete

TP3000 programming:

1. Press ##
2. Enter OTKSL
3. Scroll to SAVE and press OK
4. Open flip
5. Use Stylus to enter the 10 digit MIN
6. Press OK (No SID entry is required)
7. Programming is complete

TP 5250 programming:

1. Press ##
2. Enter the OTKSL
3. Scroll to SAVE and press OK
4. The phone display will read SVC Program
5. Scroll to MOBILE PHONE # and press OK
6. Phone display will read Mobile Phone Number
7. Enter the 10 digit MIN and press OK
8. Scroll to Home SID and press OK
9. Enter the 4 digit SID (4654) and press OK
10. Reset Phone will be highlighted. Press OK
11. Phone will reset
12. Programming is complete

LG V111(DM110) programming:

[menu]30.

After ask lockcode, enter: 843691.

Ericsson programming:

Shot NAM 987 + menu

Long NAM 923885 + menu and enter SPC: "000000"

or may be other SPC typed by user.

CDMA mode 904093 + menu

Analog mode 904095 + menu DM mode 904959 + menu

Hyundai:

HGC-120E / -130E programming:

#86904**89397#

HGC-600E programming:

##20022002, END and enter SPC: "000000"
or may be other SPC typed by user.

Sony:

CM-M1300/3300/Z200 programming:

type "111111" and press Jog Dial.
Choose "Programming" and enter SPC: "000000"
or may be other SPC typed by user.

Sony CM-M1300:

1. Power phone on
2. Enter six "1s" (111111)
3. Press the jog dial in
4. Press the jog dial in again to select programming
5. Enter six "0s" for the service security code
6. Phone displays the ESN
7. Press the jog dial in for OK
8. Enter your ten digit cellular telephone number
9. Press the jog dial in for OK
10. Enter your cellular carrier's system ID (SID) without the zeros
(Example: if your carrier's system ID is 00035, enter just 35)
11. Press the jog dial in for OK
12. Enter a name for NAM 1 or just press the jog dial in for OK
13. Phone displays Basic NAM 1 Programming is complete
14. Press the jog dial in
15. Press the jog dial in again for EXIT
16. Phone powers itself off
17. Press the power button to power the phone back on
18. Basic programming is complete

Motorola:

StarTAC 7760/7860 programming:

Service menu: FCN+0+000000+000000+RCL
Test mode: FCN 00**83786633 STO

V60c programming:

Service menu: 74663 # [Menu] [Menu] (programming code)
Test mode: [Menu] 073887 * (security code = 000000)

Motorola Tarpon (120x) programming:

1. Press 74663 (spells PHONE)
1. Press # MENU MENU quickly
2. Enter OTKSL
3. The work MIN will be highlighted
4. Select the word CHANGE by selecting the top right button
5. Select DELETE. Press and hold the button until clear
6. Have the customer enter the 10 digit MIN number

7. Select OK with the top right button.
The "User Activation" screen will appear
8. Scroll to highlight the CDMA Sys ID
9. Select CHANGE by selecting the top right button
10. Enter SID
11. Select OK by selecting the top right button
12. Select DONE with the top left button
13. Press the END key
14. Press # MENU MENU quickly
15. Enter OTKSL
16. The work MIN will be highlighted
17. Select the word CHANGE by selecting the top right button
18. Select DELETE. Press and hold the button until clear
19. Have the customer enter the 10 digit MIN number
20. Select OK with the top right button.
The "User Activation" screen will appear
21. Scroll to highlight the CDMA Sys ID
22. Select CHANGE by selecting the top right button
23. Enter SID
24. Select OK by selecting the top right button
25. Select DONE with the top left button
26. Press the END key

Motorola Phones (ALL):

1. Enter 74663 # FCN FCN
2. Enter OTKSL
3. Enter MIN and press STO
4. Enter SID (4654) and press STO
5. Press STO again - programming is complete

Note: on the Tarpon (120C) you will need to press the MENU key instead of FCN.

Nokia:

5185/6185 programming: *3001#12345#
 Software version: *#837# or *#VER# or *#9999#
 Serial / ESN: *#92772689# or *#WARRANTY#
 Phone reset: *#75681# or *#75682#

Nokia 6185-5170:

1. Press *#639#
2. Enter OTKSL and press OK
3. Enter the MIN and select OK
4. Enter the SID and select OK
5. Programming is complete

Nokia 3585:

1. Enter ## followed by the OTKSL
2. Number (MDN) is highlighted. Press the upper left-hand soft key to select
3. Mobile Number will display. Enter the 10 digit MIN
4. Press OK
5. IMSI will appear. Press and hold the Clear key until the display is empty.

6. Enter 31000 plus the MSID (15 digits total)
7. Press the upper left hand soft key and select OK
8. It will take you back to the SVC Programming.
Press the upper right hand soft key to select EXIT
9. Press END.
10. Phone will power cycle and programming is complete.

SK Teletech:

SK-IM 1000/1400/2000/2200/2400 programming: **#7583538324#626#**

Getrun 2000:

System NAM programming mode: 0 + 1 + # + 7 + 3 + 7 + SECURITY CODE (**000000**)

Debug menu: 0 + 1 + # + 3 + 2 + 4 + SECURITY CODE (000000)

Debug screen of field test mode: 0 + 1 + # + 7 + 2 + 7

Test mode: 0 + 1 + # + 7 + 6 + 4 + SECURITY CODE (000000)

System test mode: 0 + 1 + # + 7 + 6 + 8 + SECURITY CODE (**000000**)

NEOPOINT:

Neopoint 1000:

1. Press M to display Main Menu
2. Scroll to PREFERENCES
3. Press softkey under SELECT
4. Enter 040793
5. Scroll to PROGRAMMING
6. Press softkey under SELECT
7. Enter OTKSL
8. Press softkey under DONE
9. Scroll to PHONE NUMBER
10. Enter 10 digit MIN
11. Scroll to HOME SID
12. Enter SID (4654)
13. Press softkey under SAVE to exit
14. Programming is complete

NEOPOINT 1600

1. Power the phone on
2. Press the "Menu" key
3. Scroll to "Preferences" - press "Select"
4. Key in the "Field Service Code" (the phone will not prompt you for the code)
at the "preferences" screen to access the "Service" menu (Default code is "**000000**")
5. Scroll to "Programming" - press "Select"
- the phone will ask for the "Subsidy Lock Code"
6. Enter the "Subsidy Lock Code(654321)" to access the "NAM" menu
7. Select the NAM to be programmed (NAM 1 or NAM 2)
8. Program the NAM - Phone number and CDMA Home SID
9. After programming has been completed press "Save" - the phone will reset

Audiovox:

Audiovox 9100:

1. Press ##

2. Enter the OTKSL
3. Display will read Service/Menu 1 Basic...press OK
4. Next screen will read Service Mode/Home SID...press OK
5. Next screen will read Service Mode/Home SID...press OK
6. Device will display Service Menu 1. Basic #
7. Press END button to complete programming

Handspring TREO:

1. Open the flip and press the PHONEBOOK button one time to display the dial pad
2. Enter ## and the OTKSL using the numbers on the Dial Pad
3. Press the handset button shown in the diagram above
4. At the Activations screen enter the MIN
in the phone number field using the numbers on the device keyboard
5. Put a check in the Enabl Number Portability box and type the MSID in the MSIN field
6. Press OK
7. The device will display the network search pop-up and return to the Phonebook display

Hitachi P300:

1. Enter ## and the 6 digit OTKSL
2. Press the Options soft key and then scroll to Save Phone #.
Press the OK soft key.
3. At the NAM display scroll to EDIT and press the OK soft key
4. Display will read NAM and MDN will be highlighted. Press the OK soft key.
5. At the MDN display enter the 10 digit MIN and press the SAVE soft key.
6. At the Save prompt press the OK soft key.
- The next display will show several options that should not edited.
7. Press the EXIT soft key and the device will power cycle.
8. Programming is complete.

Kyosera:

Kyocera 2345 1135

1. Press 111111 (#1 key 6 times)
2. Option will be highlighted
3. Press OK
4. Scroll down to Programming
5. The service programming dialog will appear Enter Security Code.
6. Enter the 6 digit OTSKL (code will show as asterisks on screen)
7. Service Options will appear
8. Scroll down to the BASIC NAM1 Info
9. Press OK
10. Select the Phone Number by pressing the OK key
11. Using the keypad enter the 10 digit MIN
12. Press OK
13. Press END to complete the programming

Kyocera 6035:

1. Press 1 six times (111111) and select OPTIONS
2. Select PROGRAMMING
3. Open flip
4. Tap the OTKSL on keypad on the screen. Tap OK

5. Tap on the PHONE NUMBER field. Enter MIN.
6. Leave A-KEY blank
7. Enter HOME SID (4654)
8. Tap SAVE & EXIT
9. Tap YES
10. Phone will be in OFF MODE Close flip.

Kyocera 3035:

1. Press 111111 (the #1 key six times)
2. Options will be highlighted
3. Press in the navigation key
(Navigation key is the button located between the TALK & END key)
4. Scroll to PROGRAMMING using the Navigation key
5. Select PROGRAMMING by pressing in the Navigation key
6. Enter the six digit OTKSL and press in the navigation key
7. SERVICE OPTIONS will appear
8. Scroll down to the Basic NAM1 info
9. Press in the navigation key
10. Clear any numbers that may appear using the "clear" key
(arrow key located directly below the navigation key)
11. Select the PHONE NUMBER by pressing in the navigation key
12. Enter the 10 digit MIN select OK by pressing in the navigation key
13. Press END. Programming is complete.

Kyocera 2255:

1. Press the 1 key six times (111111) "Option will be highlighted
2. Press OK
3. Scroll down to "Programming" and press "OK"
4. Enter OTKSL and press the navigation key
5. "Service Options" will appear scroll down to the "Basic NAM1 Info"
6. Press OK
7. Select Phone Number by pressing OK
8. Enter MIN and press OK again
9. Scroll to Home SID and press OK
10. Enter SID (4654) and press OK
11. Press END. Programming is complete.

QCP 2035:

1. Press 1 six times (111111)
2. Press u key to select OPTIONS
3. Highlight PROGRAMMING and press u key
4. Enter OTKSL
5. ESN will appear press left arrow key to select OK
6. Enter MIN and press 3 key
7. Press 3 key again to exit - Programming is complete

Sanyo:

Sanyo 4000 4500 4700 5000 6000:

1. Press ##
2. Enter the OTKSL

3. Scroll to SAVE and press OK
4. ESN will be displayed - press OK
5. Enter 10 digit MIN and press OK
6. Enter SID (4654) and press OK
7. Press OK twice
8. Programming is complete

Sanyo 5150 5300 and 6400:

1. Enter ## followed by the OTKSL
2. Press MENU SAVE PHONE #
3. Press Ok
4. SVC Programming will be displayed.
Scroll and highlight Mobile Number. Press OK
5. Press OK again
6. ESN will be displayed. Press OK
7. Mobile Number will be displayed enter the 10 digit MIN press OK
8. Press OK 4 times
9. Phone will power cycle
10. Programming is complete

Sanyo 6000:

1. Press ##
2. Enter OTKSL
3. Press MENU Key and scroll to SAVE PHONE # and press OK
4. ESN will be displayed press OK
5. Enter MIN and press OK
6. Enter SID and press OK
7. Press OK twice more
8. Programming is complete

Sanyo 4900:

1. Enter ## followed by the 6 digit OTKSL
2. Press the MENU/OK key and scroll and highlight SAVE PHONE #
3. Press MENU/OK
4. Scroll and highlight MOBILE NUMBER press OK
5. At the ESN display press OK
6. In the MOBILE NUMBER screen enter your MIN and press OK 4 times
7. At the service program menu scroll to exit and press the MENU/OK key.
8. Programming is complete

Sanyo 6200:

1. Enter ##
2. Enter OTKSL
3. Press the MENU key and scroll to highlight SAVE PHONE #
4. Press OK
5. Scroll and highlight MOBILE NUMBER
6. Press OK twice
7. Scroll and highlight EXIT
8. Press OK
9. Phone will power cycle

10. Programming is complete

Toshiba 2032P:

1. Slide the Radio Standby Switch on the left side of the device to the upper side (ON) to activate the phone function.

This is the switch with the phone icon over it

2. After power up is completed use the stylus to tap on the ADMIN pull up menu at the bottom of the screen and select ACTIVATION WIZARD.

If your device has not yet been activated the ACTIVATION WIZARD will automatically start when you turn on the radio in your device.

3. Tap NEXT 3 times.

If the device has been previously activated it will require only 2 presses.

4. On the fourth screen enter the 6 digit OTKSL using keyboard

5. Enter the MIN in both entry fields then tap NEXT

6. Wait for the device to initialize and display "ready to connect"

7. To initiate IOTA tap the word ADMIN at the bottom of the display and then Data Provisioning

8. Programming is complete

Synertek:

Code for NAM Programming Mode : Synertek S-200

NAM Set : [MENU] [0] [SPC CODE]

Test Vibro/Rx/Tx/ [#] [#] [5] [5] [5] [5] [SAVE]

Debug Screen: [#] [#] [3] [3] [SAVE]

Debug Screen: [#] [#] [5] [2] [3] [SAVE]

Unknou Code !!!: [#] [#] [3] [2] [5] [SAVE]

Rf Test: [#] [#] [#] [#] [SAVE]

Curitel:

Code for NAM Programming Mode : Hyundai hx510b/h100/h150(Curitel)

NAM Set: [#] [#] [2] [0] [0] [2] [2] [0] [0] [2] [PWR] [1] [SPC CODE]

Field Teste :[#] [#] [2] [0] [0] [2] [2] [0] [0] [2] [PWR] [1] [MASTER CODE]

Enter A-KEY: [2] [5] [3] [9] [*] [*]

Debug Menu: [#] [#] [2] [7] [7] [3] [2] [7] [2] [6][PWR]

SAR Test: [#] [#] [2] [7] [7] [5] [2] [3] [4] [5] [PWR]

Baud rate: [#] [#] [3] [6] [*] [*] [PWR]

DM mode Enable: [*] [*] [1] [0] [0] [4] [PWR]

DS mode Enable: [*] [*] [1] [0] [0] [5] [PWR]

Test Bell/Led/Voice/Dot:[#] [#] [1] [1] [2] [2] [PWR]

RF mode: [#] [#] [2] [2] [4] [0] [PWR]

RAS RAM: [#] [#] [2] [7] [7] [4] [PWR]

CMUX 1: [*] [*] [0] [4] [8] [1] [PWR]

CMUX 2: [*] [*] [0] [4] [8] [2] [PWR]

RX mode FAX: [*] [*] [0] [4] [9] [2] [PWR]

RX mode DATA: [*] [*] [0] [4] [9] [1] [PWR]

RX mode RESET: [*] [*] [0] [4] [9] [0] [PWR]

Here is a list of various codes to try out. Some may require an MSL to be able to make full use of the functionality.

##2769737	[##BROWSER]	MiniBrowser Settings (2G)
##8626337	[##VOCODER]	Set Vocoder
##3282 f0	[##DATA]	Setup Menu for Vision handsets
##8463	[##TIME]	Airtime Menu
##040793		Debug Menu
##786	[##RUN]	Technical Information
be careful with this one, you can reset the handset)		
##932	[##WEB]	IP Address information (2G)
##889	[##TTY]	TTY On or TTY Off
##4357	[##HELP]	Help

احمد نوروزي lahmadnoroozi1372.blogfa.com

Dancall Service Codes

*#06#	IMEI
*#9999#	Firmware
*#9998#	Configuration
*#9997#	Selftest
*#9994#	Serial number (DANCALL HP 2731)
*#9993#	Adding "Engineering functions"
*#9990#	Battery monitor
*#9000#	SIM Lock
*#9001#	Group SIM Lock
*#9002#	Operator SIM Lock
*#9003#	Network SIM Lock
M1599955	Time to discharge

احمد نوروزي

ahmadnoroozi1372.blogfa.com

Hadenuk Service Codes

*#06#	IMEI
--------------	------

##9140*83#75*2# Soft Version

ahmadnoroozi1372.blogfa.com

احمد نوروزي

LG Service Codes

***#06#** - Show IMEI

***#07#** - Show IMEI & SV version

All Service Menu

2945##

LG - 200

***789# + Send**

LG - 500, LG - 600

2945#(*)- hold (* удерживать до появления меню)

8060## - просмотр версии прошивки и железа

2947## - Lock/Unlock SIM

9270## и 9278## - коды, НЕРАБОТАЮЩИЕ с LG-500

(возможно, работают с другими моделями LG).

LG - 500

2945# * - (удерживать)

LG - 510

2945##

2945#*1# (второе сервисное меню)

2945## (без всяких "долгих" удерживаний) - Engin. mode

LG - 600

2945# * - (удерживать)

LG-1200

***8375# - тестовый**

LG - 5200

2945##

LG 8110, LG 8120

47328545454# or 277634## Security Removing Code

B1200

***8375#**

***+ pwr, 6, 6, 8** Service Menu

***6861# -** инициализация после загрузки ПО
***8375#**

B1300

***+ pwr, 1, 5, 9** Service Menu

W3000 G5300 C1200 G7100...

2945## - service menu (code reset)

G1800:

[2945##] Service Menu

[*#3646633#] Engenering Menu

***6861#** Factory reset
***8375#** Factory reset
#668# Factory reset
***#3646633#** Factory reset
***0008#** Change language
***0009#** Change language
***0000#** Change language
***7245786#** Check read FFS
***762442#** GVCMMI Magic
1945##5101# Sim lock menu
***3241#**
***3240#**
***7674#**
***76863#**
***774 3#**
***72337#**
***79763#**
###765*02#
###765*05#
###765*08#
###765*07#
###765*78#
2945##5100#

ahmadnoroozi1372.blogfa.com

احمد نوروزي

Switch

90E05 - Ericsson T28
90E06 - Ericsson T20
90E07 - Ericsson T20 / T28 / R320, Nokia 8210 / 6210
90E08 - Ericsson T28, Nokia 8210

EF 9XG	- Ericsson T28
0512(0518, 0519)	- Ericsson T68
0518B	- Siemens C35 / A35, Nokia 3310
0503	- Siemens C35, Ericsson T10 / A2618 / A1018, Nokia 3310
0506	- Nokia 3310
0507A	- Nokia 3310, Ericsson A2618
SP Z BB101	- Nokia 3510i
mld 2N2 (blue)	- Working with Nokia 6210 / 8210 / 6310i
KCD 282	- Nokia 6310
XP215	- Siemens C45
DFY21R74	- Nokia 5110 / 6110
N50 02A	- Samsung T100
L50 08C	- Samsung R210
90D	- Samsung 2100
0501B	- Alcatel BE4
0511A	- Sony CD5

ahmadnoroozi1372.blogfa.com

احمدنوروزي

Motorola Service Codes

***#06#** IMEI

P2K test menu:

#06#, menu, menu, 048263

P2K Test comands:

32*116*1*0*0	- Read phone code
32*118*1*0*0	- Read security code
18*0	- Factory reset, phone code off
18*1	- Master reset
54*18*1	- Full phone reset
10*0*6	- Select 900/1800
32*279*1*0*8	- Model
32*383*1*0*0	- Flex version

Motorola MPX200, MPX220, MPX100 Сервисные коды

Hard reset MPX200, MPX220 - blue button + power on

- blue button + power on	Hard reset
****837#	Version info
****372#	FQC
****364#	Engineering menu

***266*0#	Set as data COM port
***266*1#	Set as log COM port
***797#	Time to failure timer & Power down code
***2263*0#	Set to default Band
***2263*1#	Disable GSM Band
***2263*2#	Disable DCS Band
***2263*3#	Disable EGSM and DCS Band
***2263*4#	Disable PCS Band

после ввода жмете кнопочку SEND.

Motorola E365 Сервисные коды

#02#-check version

#02#-проверка версии

#02# - версия прошивки, железа и т.п.

#03#-мониторинг сети

#03#-net monitor

#04#-мониторинг батареи

#04#-battery menu

#08#-efem меню

#08#-efem menu

#09# тест кнопок, звука, экрана

#09# test all

#09# тест телефона

****0101#** -test sim auto answer

****0102#** -WARNING!!! fingr format(лучше сначала сделать backup!!)

****0104#** -select on/off (Только чего? ... не понял)

****0105#** -engineer menu off

****0105#** -engineer menu off

****0106#** - engineer menu

****0106#** - инженерное меню (только шрифт там не меняй...)

audio g1033gain

audio path (both, external, internal)

aec mode (Long/short select, aec reset, noise limit, aec echo, aec)

lcd mode (contrast, bright)

melody

font view (12X12 or 7x12)

vibrate

lcd test

adc view

driver test all

****0107#** - чего-то так быстро показал со значком ошибки,

что не понятно, что это

****0108#** failure counter

****0109#** TFT counter reset

073887 разблокировка Sim. Пароль при вводе "000000".

Сервисные коды Motorola C350

Сервисное меню в Motorola C350

Для входа в сервисное меню надо быстро нажать комбинацию следующих кнопок: Меню048263*

На экране должно появиться приглашение для ввода команд:

Orpcode:_____

Дальше можно вводить команды,
например, **54*18*1** - полный сброс телефона.

(54* - обязательное начало для всех команд)

Команды:

0*0*0 - Select tone 0

0*0*1 - Select tone 1

0*0*2 - Select tone 2

0*0*3 - Select tone 3

0*0*4 - Select tone 4

0*0*5 - Select tone 5

0*0*6 - Select tone 6

0*0*7 - Select tone 7

0*0*8 - Select tone 8

0*0*9 - Select tone 9

0*0*124 - Select tone 1 KHz

0*0*125 - Select tone 2 KHz

0*0*126 - Select tone 3 KHz

0*0*127 - Select tone 4 KHz

0*1*X - Disable tone X

3*0*1 - Enable vibrator

3*0*0 - Disable vibrator

4*3*1 - Enable speech coder full rate Audio loopback

4*3*0 - Disable speech coder full rate

4*4*1 - Enable speech coder enhanced full rate

Troubleshooting C350 Series

4*4*0 - Disable speech coder enhanced full rate

4*5*1 - Enable speech coder half rate

4*5*0 - Disable speech coder half rate

5*0*0 - Set audio level 0 Audio level

5*0*1 - Set audio level 1

5*0*2 - Set audio level 2

5*0*3 - Set audio level 3

5*0*4 - Set audio level 4

5*0*5 - Set audio level 5

5*0*6 - Set audio level 6

5*0*7 - Set audio level 7

5*0*8 - Set audio level 8

5*0*9 - Set audio level 9
5*0*10 - Set audio level 10
5*0*11 - Set audio level 11
5*0*12 - Set audio level 12
5*0*13 - Set audio level 13
5*0*14 - Set audio level 14
5*0*15 - Set audio level 15
6*2*2*0*0 - Set Audio Path.
Int Mic, IntSpk, RX unmute, TX unmute

6*4*6*0*0 - Set Audio Path.
Boom Mic, Boom Spk, RX unmute, TX unmute

10*0*3 - Set band GSM 900
10*0*4 - Set band DCS 1800
10*0*5 - Set band PCS 1900
10*0*6 - Set dual band GSM 900 / 1800
10*1*0 - Read band 3= GSM 4= DCS 5= PCS 6 =GSM/DCS
18*0 - Initialize non-volatile memory (Master Reset)
18*1 - Initialize Non-volatile memory (Master Clear)
20*X*0 - Load Channel number X Select Channel
(Used for debugging Rx mode)

0*1*0 - Load channel number 1 GSM Low channel
20*62*0 - Load channel number 62 GSM Mid channel
20*124*0 - Load channel number 124 GSM High channel
20*512*0 - Load channel number 512 DCS Low channel
20*700*0 - Load channel number 700 DCS Mid channel
20*885*0 - Load channel number 885 CDS High channel
20*512*0 - Load channel number 512 PCS Low channel
20*661*0 - Load channel number 661 PCS Mid channel
20*810*0 - Load channel number 810 PCS High channel

55*2*001 - Test Display. All pixels ON
55*2*000 - Test Display. All pixels OFF
55*2*002 - Test Display. Checkerboard pattern A

Table 2. Manual Test Commands (Continued)

Key Sequence Test Function/Name Remarks

Level 1 and 2 Service Manual Troubleshooting

55*2*003 - Test Display. Checkerboard pattern B

55*2*004 - Test Display. Border pixels ON

*#06# - IMEI Check No Test Mode Required

ВКЛЮЧЕНИЕ НЕТМОНИТОРА: Меню 00**83786633*

ВЫЛЮЧЕНИЕ НЕТМОНИТОРА: MENU 00**83786633*

нажимать надо очень быстро.

Выключаете трубку, и он появляется при каждом включении.

Выйти в меню/обратно: меню - левая софт кнопка

in permanent test mode

(* hold 2 sec)

***113*1*[OK] net monitor

MOTOROLA 3xx

#06# and quick 'menu-key' and 048263 (Push the key quickly!)
and entering at field "OPTCODE" you must try several times.
If not working try with MOTO TEST CARD inserted.

Security code - 32*118*1*0*0

Model - 32*279*1*0*8

Flex ver - 32*383*1*0*0

Master Reset - 18*0

Master Clear - 18*1

Set band GSM 900 - 10*0*3

Set band DCS 1800 - 10*0*4

Set band PCS 1900 - 10*0*5

Set dual band GSM 900/1800 - 10*0*6

Read band - 10*1*0 => 3-GSM, 4-DCS, 5-PCS, 6-GSM/DCS

User code - 32*116*1*0*0 /coded:00310032003300340000 - 1234/

Read imei - 32*4*1*0*0 "OK" /coded:083a05092700247709 - 350907200427799/

47*4*1*0*9*081A32547698103254 => IMEI=123456789012345

it is possible to change IMEI

T205/T19x (ACER)

Motorola T190, T191, C200, C205, T205

Master Code - **19980722, 20010903**

*#300# OK	List the Software and Hardware version
*#301# OK	Full Keypads functional Test
*#303# OK	Set Default Language to English
*#304# OK	Set OFF engineering mode
#304*19980722# OK	Set ON engineering mode
*#305# OK	Location: 1 OK
*#307# OK	Engineering Test Mode
*#311# OK	Phone code changed to default code
#400# OK	ADC, Cal val
*#402# OK	Adjust Display Intensity / Contrast
*#403# OK	List the Manufacturing Informations
19980722 OK	Master Unlock code for Phone and Sim Lock

*3370# EFR ON (enhanced full rate)

#3370# ERF OFF

*#72837726# OK Confirm ?, Data saver

1234 OK Phone code default

*#0000# OK Setting saved, restore set phone do default language

*#0048# OK Fast change polish langpack

*#0007# OK Fast change russian langpack

*#302# OK

Acoustic test*

- 7.1 Greeting
- 7.2 Main VlmGain
- 7.3 Input Cal
- 7.4 Output Cal
- 7.5 Side In Gain
- 7.6 Vox Gain
- 7.7 Min Mic Engy
- 7.8 M re
- (a) In Vlm Gain
- (b) Aux Vlm Gain
- (c) Silence Prd
- (d) Supp Prd
- (e) In Volume
- (f) Out Volume
- (g) Icon
- (h) Image
- (i) Animation

Остальные коды работают только в "тест-режиме".

Его можно разблокировать,
используя программу Compal Service Tool
заходим в Handset Specific.

Жмём кнопку Read Data. Ждём, пока появится версия прошивки,
FLEX-а и т.д. Дальше нажимаем кнопку EFEM ON.

В окне Message, которое открывается при запуске программы,
должно быть написано:

Trying to Write Data to MS...

EFEM Set OK!

Read Handset Specific Data Begin.

Всё "тест-режим" включён.

#08# - "эксперт-меню"

#03# - сеть - монитор уровня RF сигнала

(для отключения кода ввести его ещё раз)

#04# - батарея - монитор уровней напряжений в контрольных точках

(для отключения кода ввести его ещё раз)

**0108# - управление счётчиком ошибок

**0101# - Test SIM auto answer

**0102# - сброс всех настроек, мелодий, записной книги и т.д.

**0105# - выход из "тест-режима"

**0106# - инженерное меню

**0109# - сброс счетчика TFT (значение можно посмотреть, введя #02#)

Maxon Service Codes

- *#9922# - Menu, reset (without SIM)
- *#9900# - Software Version
- *#9901# - Software Version (PBatch)
- *#9911# - L1 Debug on/off
- *#9915# - Back to default
- *#9916# - Text (scroll up/down)
- *#9917# - Lock status
- *#9934# - Bd config
- *#9935# - FC init
- *#9936# - TOC init
- *#9937# - Discharging battery
- *#9940# - Pins
- *#9941# - Testsignal
- *#9953# - Phone off
- *#9957# - Select 2-3 Menu lines
- *#9958# - Watch stop
- *#9959# - Watch start
- *#9960# - Contrast set
- *#9962# - SMS Menu
- *#9988# - Tetris Play
- *#9999# - Oem Id

MTC Service Codes

*#06# IMEI

Без карты:

Тест-режим - **878** (TST по буквенной клавиатуре)

Посмотреть версию - ****

С картой:

Версия1: ***#0000#**

Версия2: ***#0001#**

Версия3: ***#00000#**

Похоже, что есть еще код, но при каких условиях он работает и что делает - непонятно: **77899*#**
вот ещё не много кодов:

#*0000#
***#00000#**
***#0001#**
***#684#**
***#324#**
***#2786#**
***#2789#**
***#28869#**
***#28866#**
***#324564.IMEI**

Как попасть в меню блокировок, увы, не знаю - не нашел.
Может вообще заблокировано это меню, хотя кто ж знает.

ahmadnoroozi1372.blogfa.com

احمد نوروزي

Nec Service Codes

*#06#	IMEI
*#73738# (send?)	Reset to defaults
*#2820#	Software version

SP Lock info:

*#3210# (send?)	For Sim lock info
*#8140# (send?)	For Net lock info

[password is an 8 digits number]

Sim Lock ***#4960# (send?)** - Inquiry * 4969 * password * password # (send?)

Net Lock ***#7320# (send?)** - Inquiry * 7320 * password * password # (send?)

Net Lock 2 ***#2220# (send?)** - Inquiry * 2220 * password * password # (send?)

Subnet Lock ***#1110# (send?)** - Inquiry * 1110 * password * password # (send?)

ahmadnoroozi1372.blogfa.com

احمد نوروزي

Philips Service Codes

***#06#** IMEI

***#2254*#** Status register: C, BS, RR, MMI, CREAT

***#2255*#** activate and deactivate the "DEBUG CALL" -Mode;
when activated, make a call to busy line an the phone will display
some hex codes on the display

Philips 350

***#7728*#** - Reset Phone

Philips 630

#20021208# ok - without SIM (erase flash, unlock)

***#7728*#** - RSAV DONE

***#3849*#** - ??? Reboot

***#3851*#** - ??? Reboot

Philips 568

***01763*737381#** - Reset

***#2558*#** the time in days, hours and minutes you are connected to the net

***#2562*#** not clear; the phone reconnect to the net

***#2565*#** not clear; warmstart ?

***#3333*#** (NO) blocking -list (15 items)

***#2377*#** "BEER": not clear the phone waits a random time and reconnect to net,
sometimes make reset

***#3377*#** Init, Flags, SIM LOCK

***#3353*#** reset the (NO) BLOCKING list

***#7378*#** Name, Length, SIM phase

***#7489*#** Security Code

***#7693*#** you can activate and deactivate the Sleep Menu
(when deactivated the battery will go down!)

***#7787*#** not clear: Spurious Interrupt

***#7948*#** Switch Off: not clear: it is a timer or something

***#8463*#** Some information about the SLEEP MODE:
Wake, Sleep Req., Sleep

GENIE (TCD838)

***#2337*#** and it will be activate the beep signal
when the phone reconnected to the net.

FIZZ

***#8377*#** software version

***#1234#** or ***#7489#** Security code

***#5644*#** software version (enlarge)

***#8377*#** simlock status

OZEO

***#7826*#** master reset
***#5187*#** L1TR
***#3877*#** hanging mobile for a while
***#7462*#** to SIM PHASE 2
***#7626*#** ?
***#7676*#** ?

ahmadnoroozi1372.blogfa.com

احمدنوروزي

Panasonic Service Codes

***#06#** IMEI
746, menu, menu lock menu
***369#(*)** Menu
***#9999# - 5 sec after power on** SW version (**GD75, GD67, GD87..**)
***01763*737381#** Master reset
(User data, User code) **A100, A101, A102, G50, G51, GD55, G70...**

GD93 default key lock code - **0000 OK**

ahmadnoroozi1372.blogfa.com

احمدنوروزي

Pantech Service Codes

***01763*737381#** - master reset (user data, user code) without SIM
***01763*737381# (*01763*RESET1#)** - Системный сброс
(все настройки по умолчанию)
***01763*8371#** - SW version
***01763*6371#** - UNLOCK
***01763*3641#** - Menu
***01763*476#** - Тесты телефона

***01763*3640# (*01763*ENG0#)** - Выключить инженерный режим
***01763*3641# (*01763*ENG1#)** - Включить инженерный режим

***01763*6370# (*01763*MEP0#)** - Выключить MEP menu

(Menu-5-4-(1234OK)-7) - разлочка
***01763*6371# (*01763*MEP1#)** - Включить MEP menu
(Menu-5-4-(1234OK)-7) - разлочка

Pantech G500 G600 G700 G800 G900 GI100 GF200:

***01763*727#** - ?
***01763*62766#** - ?
***01763*68726#** - ?
***01763*34531#** - ?
***01763*476#** - Tests
***01763*546360#** - LineN0 ?
***01763*546361#** - LineN1 ?
***01763*546364#** - LineN4 ?
***01763*546367#** - LineN7 ?
***01763*5640# (*01763*LOG0#)** - Disable LOG
***01763*5641# (*01763*LOG1#)** - Enable LOG
***01763*6370# (*01763*MEP0#)** - Disable MEP menu (unlock menu)
***01763*6371# (*01763*MEP1#)** - Enable MEP menu (unlock menu)
***01763*3640# (*01763*ENG0#)** - Disable Engineer Mode
***01763*3641# (*01763*ENG1#)** - Enable Engineer Mode
***01763*63866330# (*01763*NETMODE0#)** - Disable NetMode
***01763*63866331# (*01763*NETMODE1#)** - Enable NetMode
***01763*737381# (*01763*RESET1#)** - System reset (all default settings)

ADDITIONAL CODES - ДОПОЛНИТЕЛЬНЫЕ КОДЫ:

Pantech G500

[GIHR0507042004 ZEUS Ver. 0.01s]

***01763*225837#** - ?
01763*22637266# (*01763*CAMERAON#) - Camera test mode on

Pantech G600

[GZBP0105102004 PANTECH ver 1.0]

***01763*22637266# (*01763*CAMERAON#)** - Camera test mode on

Pantech G700

[GXNP0107242004 TLION ver 1.0s]

none - нет

Pantech G800

[GLAP0006062004 G800 ver 1.0N]

***01763*28271#** - ?
***01763*28270#** - ?
***01763*2873738#** - ?
***01763*288#** - ?
***01763*79837# (*01763*SWVER#)** - Soft are version
***01763*22637266# (*01763*CAMERAON#)** - Camera test mode on

Pantech G900

[GWP0206282004 G900 ver 1.0b]

***01763*79837# (*01763*SWVER#)** - SoftWare version
***01763*22637266# (*01763*CAMERAON#)** - Camera test mode on
***01763*92782#** - copy UaData..... copy httpUserAgent.....Call Edit Mode : %s ?
***01763*927827763#** - copy UaProfData..... copy httpUserAgentProf..... ?

Pantech GI100

[GMAP0212132004GI100 ver 1.0]

***01763*47865625#** - ?
***01763*79837# (*01763*SWVER#)** - SoftWare version
***01763*22637266# (*01763*CAMERAON#)** - Camera test mode on
***01763*92782#** - copy UaData..... copy httpUserAgent.....Call Edit Mode : %s ?
***01763*927827763#** - copy UaProfData..... copy httpUserAgentProf..... ?

Pantech GF200

[GTCP0007292004GF200 ver 1.00]

***01763*66756#** - ?
***01763*79837# (*01763*SWVER#)** - SoftWare version
***01763*92782#** - copy UaData..... copy httpUserAgent.....Call Edit Mode : %s ?
***01763*927827763#** - copy UaProfData..... copy httpUserAgentProf..... ?

ahmadnoroozi1372.blogfa.com

احمد نوروزي

Power Amplifier

Alcatel HE1	M2006
Alcatel HD1	M2006
Alcatel BE1	PF0414B, PF01411B
Alcatel BE3	PF0414B, PF01411B
Alcatel BE5	NMP70731
Alcatel BF4	PF0107
Bosch 509 Dual	RF2138, RF2140
Bosch Com 607	PF01411A
Bosch 909 Dual	RF2138, RF2140
Ericsson GH688	PF01410A
Ericsson GA318	SHARPTQ-G400 PF0144
Ericsson GH198	PF1014-01
Ericsson GA318	PF0148E
Ericsson GA628	PF01410A
Ericsson A2618s	40305/1, 40305/2, T105, T013
Ericsson A1018s	T014, T934, PF08105A
Ericsson R310s	T031
Ericsson R320s	RM009-19

Ericsson T10s	AND630
Ericsson T20e	RM009-19P
Ericsson T28s	RM009-19P
Ericsson T29s	RM009-19
Ericsson T39s	RF2174, RF2173
Ericsson T68	CX77302
Maxon MX-6869	PF01411A
Maxon MX-6820	RM009-19
Maxon MX-3204	PF01411A
Mitsubishi Astral	F9001
Mitsubishi Aria	F9001
Mitsubishi Mars	F9006
Motorola T191	CX77301-13 like T28s
Motorola T205	RM009-21P
Motorola V3688	AP119
Motorola V50	AP119 (DCS) AP120 (GSM)
NEC DB2000	PF01411B, PF0414B
NOKIA 3110	PF01412A
NOKIA 3210	PF01420B, PF04110B, BGY252, BGY262, PF01414A
NOKIA 3310	PF08109BN, BGY270, RF3103, PF1410A
NOKIA 3410	PF08109
NOKIA 3510i	PF08109B
NOKIA 5110	BGY251, BGY240, 4370319
NOKIA 5130	4370275
NOKIA 5210	PF08103B
NOKIA 6110	4370319
NOKIA 6150	4370577, 4370453
NOKIA 6210	PF08103B
NOKIA 6310	Hitachi08125B
NOKIA 6310i	Hitachi, AGILENT, RF3103, other 3310PA's
NOKIA 7110	PF01411B, PF01414B
NOKIA 8110	AWT0904
NOKIA 8210	PF08103A & B, PF08105A
NOKIA 8290	435X233
NOKIA 8810	PF01411B
NOKIA 8850	PF08103B, PF08310B
Panasonic G520	PF01417A
Panasonic GD90	PF08103B
Panasonic GD30	PF08103B
Panasonic GD52	PF08103B
Philips Genie	PF01412A
Philips Savy DB	PF08103B

Philips Savy	BGY241
Philips Diga	PF01411A
Philips Gene	PF01412A
Philips Spark	BGY204
Sagem RC715	M2006
Sagem MC922	GY2014, RF2173
Sagem MC939	GY2014
Samsung SGH-R210s	08122B
Samsung SGH-2100	PF0141B, PF0414B
Samsung SGH-2200	PF0414B
Samsung SGH-N100	PF08109B
Samsung A100	CX77301-23
Siemens SL10	PF01414A
Siemens S16	9821, 9826 like C30
Siemens S4	QCPM-9401
Siemens C25	PF08103B, PF08105A
Siemens S25	PF08103B
Siemens C35	PF08112B, PF08109
Siemens S35	PF08112B, PF08109
Siemens SL45	PF08107B, PF08122GB
Siemens C45	Hitachi 08122BG, PF08107B, PF08122GB
Siemens A50	Hitachi 08122BG
Siemens A36	PF08112B
Siemens S6 c1	PF01414A
Siemens S10	PF01414A
Siemens S40	RF2174, RF2173
Siemens C30	RF9002
Sony CMD-J6	RF2173, RF2174
Sony CMD-J5	RF2173, RF2174
Sony CMD-CD5	0014, 0012, 0015
Sony CMD-C1	9845
Kenwood	EM608E PF01411B
BENEFON TWIN	TGP71EU PF08103B

Some comments for Nokia PA'a:
10R and 10U for 33xx, 34xx
65R and 65U for 82xx, 88xx, 5210
70U for 62xx

Siemens Service Codes

***#06#** Show IMEI & SW version
***#06#** Phone Identifier (IMEI)
***#06#** и левый softkey версия прошивки и поддерживаемые протоколы
***#0606#** Sim lock status
***#0606#** проверка тела на лочку.
Должно всё стоять на Unbarried. (Только для Siemens)

***#0606#** и нажать верхнюю левую кнопку
покажет наличие блокировок
(работает только без sim-карты)

***#0003*(secret code 8 digits)#** SP unlock
***#0000#** then Green button Reset language to automatic selection
***#0001#** и green key английский язык
***#9999#** Заводские установки
(не меняет установки на SIM карте)

***4720#**, отмена **#4720#** - Уменьшает качество приема,
но увеличивает время разряда батареи
(HFR - Half Rate, продлевает жизнь батареи где-то процентов на 30,
за счет уменьшения примерно в половину полосы частот)

***3370#**, отмена **#3370#** - Улучшает качество звука и приема,
но быстрее садит батарею (EFR - Enhanced Full Rate,
система для улучшенного качества вызова в телефонах GSM,
за счет более быстрой разрядки батареи (около 5 %)
EFR использует улучшенное кодирование,

ahmadnoroozi1372.blogfa.com

احمد نوروزي

Sagem Service Codes

***#06#** IMEI

in main menu press * for HOT MENU:
lcd, led, vibra, tests, imei, software versions, battery voltage

Type MENU - 5 - 1 - 1 - # to enter Engineering Menu

Без карточки набираешь ***226632623X7**, где **X=4** или **5**

для твоего телефона и после установки времени попадаешь меню,
где по экрану ползет полоса. Нажимаешь стрелку вниз и *,
появится надпись МЕНЮ Hotline и Info telefon,
нажимаешь ОК и видишь четвертую строку сверху КОД ТЕЛЕФОНА,
заходишь и стираешь его

ahmadnoroozi1372.blogfa.com

احمدنوروزي

Sharp Service Codes

***01763*8371#** check software version type

ahmadnoroozi1372.blogfa.com

احمدنوروزي

Trium Service Codes

*#06#	IMEI
hold * 4329	Net Monitor1
hold * 621342	Net Monitor2
hold * 5472	M4 Testmode
hold * 5806	SW version
hold * 5807	HW version
hold * 936505	SW and HW version
hold * 476989	NS Lock Menu
hold * 482896	CP Lock Menu
hold * 574243	NS Lock Menu
hold * 967678	SP Lock Menu
hold * 362628	IMSI Lock Menu
hold * 787090	Lock net.level
hold * 787292	Lock net.level
hold * 3926	Shut Down...
*#0048#	Fast change polish langpack
*0000#	Automatic language
*850696	Warmstart

Eclipse:

hold * 65512890 eeprom reset - cure for hangs ect.

Voxtel Service Codes

***#06#** IMEI
0124 master code (standart phone code)
0718#(*)-hold menu (**ST11, SC10, V100** without SIM)
4268#(*)-hold show code (**ST11, SC10** without SIM)
***789#-hold** menu (**V50, V500, V300, RX100** without SIM)
0178*# держать 3 секунды Service menu

VK Mobile Service Codes

***#06#** IMEI checking code
***#79#** S/W Version checking code
0124 Master Code
***#85*364# (*)** Engineering mode Access code (Press last button for 3 secs)
8558555#(*)-hold

VG107
855855# without SIM

VG207
4268#(*)-hold

VK 900
***#85*87863#** (удерживая # нажать *) - "1" Configuration ==> "9" Cus Reset..

Unlocking Phone lock:

Insert SIM card and Power on the handset

Enter SOS key when "password" windows pops up

Enter 8558555* or 4268* (Press last button for 3 secs)

Nokia UEM

UEM 4370825

Nokia 1100 Nokia 2300 Nokia 3510 Nokia 3510i
Nokia 3600 Nokia 3650 Nokia 3660 Nokia 3100
Nokia 5100 Nokia 6100 Nokia 6200 Nokia 6310i
Nokia 6600 Nokia 6610 Nokia 8310

UEM 4376001

Nokia 3100 Nokia 6100 Nokia 6610i

UEM 4370959

Nokia 3200 Nokia 6220 Nokia 7200

UEM 4376371

Nokia 3220 Nokia 3230 Nokia 6020
Nokia 6101 Nokia 6230 Nokia 6260
Nokia 6670 Nokia 7260 Nokia 7270 Nokia 7610

UEM 437B226

Nokia 3300 Nokia 6170 Nokia 7270 Nokia 7260

UEM 4370805

Nokia 3510 Nokia 6310
Nokia 6510 Nokia 8310 Nokia 8910

UEM 4371701

Nokia 5140

UEM 4370945

Nokia 6230

UEM 4376347

Nokia 6260

UEM 4370841

Nokia 7210 Nokia 7650

UEM 4370861

Nokia 7650

UEM 4377029

Nokia 9500

UEM 4370805 P99KT0209

Nokia 8310

UEM 4370825 PKOUQO406
Nokia 5100 Nokia 6610 Nokia 7210 Nokia 7250
UEM 4370841 PKO7W0232
Nokia 8310 Nokia 8910 Nokia 6500 Nokia 7210

UEM 4370861 AEMT006C J992K241
Nokia 7650

UEM 4370945 UEME v2.0 P9G040306
Nokia 6230/7600

UEM 4370949 J9925322
Nokia 6610/7210

UEM 4376371 GK 194 UP CHN GK 507
Nokia 6230/7260/7610

UEM 4376401 UEMC44 GK 13C UJ CHN 99 543
Nokia

ahmadnoroozi1372.blogfa.com

احمدنوروزي

Zetta Service Codes

***#06#** IMEI

ZETTA A50 Unlock:

1. Включаем без сим
2. (три раза джойстик вниз)(три раза джойстик вверх)*
3. Открылась инженерка
4. Ваше дело найти пункт удалить информацию.

این کتاب به درخواست دوستان خوبم در وبلاگ برای دانلود قرار گرفت

پسدها سری کامل تری از این کدها و رمزشا میگذارم

شماره تماس :

احمدنوروزی

۰۹۳۷۹۱۹۰۱۹۴

۰۹۳۷۵۷۰۱۷۴۶

ahmadnoroozi1372.blogfa.com

احمدنوروزي